



FLAT BAR TO BE FITTED
 INSIDE ON VAN FLOOR
 BEFORE PLYWOOD FLOOR
 IS FITTED. LOCATION OF
 TAPPED HOLES TO BE
 NOTED SO THAT THEY CAN
 BE DRILL IN PLYWOOD BASE

BRACKET FITTED
 UNDER CHASIS VIEW ON B-B

236/6